



CONTENTS

1.0 GENERAL

1.1	Model Number	2
1.2	Specifications	3
1.2.1	Pneumatic Pilot	3
1.2.2	Electric Pilot	3
1.2.3	Electric Pilot Wiring	4
1.2.4	Operating Temperature Limits	4
1.2.5	Displacer Pressure Ratings	4
1.2.6	Materials of Construction / Temperature Rating	5
1.2.7	Minimum Allowable Fluid Specific Gravity	5
1.3	Model 3200 Parts List	6
1.4	Model 3201 Parts List	8
1.5	Dimensions	19

2.0 INSTALLATION

2.1	Assembly	11
2.2	Start-up	11

3.0 OPERATION

3.1	Theory of Operation	12
3.2	Level Adjustment	12
3.2.1	Liquid Interface	13
3.3	Proportional Band	13
3.3.1	Proportional Band Adjustment	13
3.4	Controller Mounting	14
3.4.1	Mounting Orientation Conversion	14
3.5	Controller Action	15
3.5.1	Controller Action Conversion	15
3.6	Snap Pilot Operation	17
3.7	Throttle Pilot Operation	17

4.0 MAINTENANCE

4.1	Preventive Maintenance	18
4.2	Troubleshooting	18

Model 3200 / 3201

Installation, Operation and Maintenance Instructions

1.0 GENERAL

1.1 Model Number Information

Sample Model Number: 3200 - 20 MS 0 - S RD B - S S

END CONNECTION SIZE		CODE	
1.50"		15	
2.00"		20	
2.50"		25	
3.00"		30	
4.00"		40	
6.00"		60	
8.00"		80	

END CONNECTION TYPE		CODE	
Screwed MNPT		MS	
Grooved		GR	
Butt-Weld, Sch. 40		B4	
Butt-Weld, Sch. 80		B8	
Butt-Weld, Sch. 160		B1	
Butt-Weld, Sch. XXH		BX	
Union Type		UT	
Slip-On Flange		SO	
Raised Face Flange		RF	
Ring Type Joint Flange		RJ	
Special - to be specified		SP	

PRESSURE RATING		CODE	
MNPT (6000 psig)		0	
ANSI 150 (275 psig)		1	
ANSI 300 (740 psig)		3	
ANSI 600 (1480 psig)		6	
ANSI 900 (2220 psig)		9	
ANSI 1500 (3750 psig)		5	
ANSI 2500 (6170 psig)		2	
Other		X	

MATERIALS OF CONSTRUCTION			CODE
Body	Shaft	Brg. Block	
1018 / A105 C.S.	303 SST	303 SST	-
1018 / A105 C.S.	316 SST	316 SST	A
1018 / A105 C.S. (NACE)	316 SST	316 SST	N

PILOT		CODE
Snap (Pneumatic On/Off)		S
Throttle (Pneumatic Modulating)		T
SPDT (Electric On/Off; explosion-proof housing)		E
DPDT (Electric On/Off; explosion-proof housing)		D

MOUNTING / CONTROLLER ACTION		CODE
Left Hand / Direct		LD
Left Hand / Reverse		LR
Right Hand / Direct		RD
Right Hand / Reverse		RR

SEAL MATERIAL		CODE
Buna-N		B
Viton		V
Special - to be specified		X

GAUGE TYPE		CODE
Brass Internals (standard)		S
316 SST Internals		3

CONTROLLER CASE		CODE
Standard		S
Piped Exhaust		P
Marine Service		M
Marine Service with Piped Exhaust		N

1.2 Specifications

1.2.1 Pneumatic Pilot

Output	Snap (On/Off)	Throttle (Modulating)
	0-20 / 0-30 psig	3-15 / 6-30 psig
Supply Pressure Requirements	20-30 psig (min)	35-40 psig (min)
Liquid Specific Gravity	Top Level: 0.35 to 2.0 Interface Level: 0.035 min. differential	
Pilot Capacity	0.282 C _v	0.394 C _v
Proportional Band Adjustment Range	20 to 150%	7 to 55%


1.2.2 Electric Pilot

Contact Rating	Electric Snap, SPDT, Explosion-proof	Electric Snap, DPDT, Explosion-proof
	<ul style="list-style-type: none"> • 15 amps @ 125, 250, or 480 VAC • 0.5 amps @ 125 VDC • 0.25 amps @ 250 VDC 	<ul style="list-style-type: none"> • 10 amps @ 125, 250, or 480 VAC • 0.3 amps @ 125 VDC • 0.15 amps @ 250 VDC
Enclosure Rating	Class I, Groups C & D, Div. 1 Class I, Group B (optional) Class II, Groups E, F, and G, Div. 1	
Approvals	UL, CSA	
Repeatability	1%	
Linearity	1.75%	
Dead Band	5% of span	
Liquid Specific Gravity	Top Level: 0.35 to 2.0 Interface Level: 0.035 min. differential	
Proportional Band Range	7 to 55%	20 to 150%

Model 3200 / 3201

Installation, Operation and Maintenance Instructions

1.2.3 Electric Pilot Wiring



1.2.4 Operating Temperature Limits

Body Material	Seals	Displacer Material	Temperature Limits	
			°F	°C
C.S.	Buna	PVC	-20° to 140°	-29° to 60°
C.S.	Buna	Acrylic	-20° to 180°	-29° to 82°
C.S.	Buna	316 SST	-20° to 180°	-29° to 82°
C.S.	Viton	PVC	-20° to 140°	-29° to 60°
C.S.	Viton	Acrylic	-20° to 200°	-29° to 93°
C.S.	Viton	316 SST	-20° to 400°	-29° to 204°

1.2.5 Displacer Pressure Ratings

Material	Maximum Pressure	
	Psig	Bar
PVC	6170	426
Acrylic	6170	426
316 SST	2000 @ 180°F ¹	138 @ 82°C ¹
	1595 @ 400°F	110 @ 204°C

1. 2000 psig pressure rating is based @ 180°F (82°C). The maximum pressure rating @ 400°F (204°C) is 1595 psig (110 bar). For applications requiring higher pressure ratings for SST displacers @ 400°F (204°C), consult Factory or your local Mallard Representative.

1.2.6 Materials of Construction / Temperature Rating

Part	Material	Wetted Part Temperature Rating
Body	Screwed or butt-weld: 1018 steel Flanged: 1018 / A105 steel	-20 to 600°F
Case & Cover	Anodized Die Cast Aluminum	N/A
Pilot Body	Anodized Aluminum	N/A
Pilot Gaskets / Diaphragm	Buna-N Viton (optional)	-20 to 180°F -20 to 400°F
Pilot Internal Valving	303 SST	N/A
Shaft	303 SST 316 SST (optional)	-70 to 600°F -70 to 600°F
Bearing Blocks	303 SST 316 SST (optional)	-70 to 600°F -70 to 600°F
Bearings	440C SST	-70 to 600°F
Seals	Buna-N Viton (optional)	-20 to 180°F -20 to 400°F
Displacer	PVC Acrylic (optional) 316 SST (optional for NACE)	-20 to 140°F -20 to 200°F -70 to 600°F
Displacer Arm	302 SST	-70 to 600°F
Vertical Hanger (Swivel)	316 SST	-70 to 600°F
Vertical Displacer Extension Chain	302 SST	-70 to 600°F
Gauges	Bronze 316 SST (optional) 316 SST liquid-filled (optional)	N/A
Torque Bar	Aluminum 303 SST (Marine option)	N/A
Flapper Bar	303 SST	N/A
Fulcrum	Nylon	N/A
Spring	SST	N/A
Spring Adjusting Knob	Aluminum 303 SST (Marine option)	N/A

1.2.7 Minimum Allowable Fluid Specific Gravity


Top Level Control					Interface Differential Detection				
Pilot	Horizontal Displacer		Vertical Displacer		Pilot	Horizontal Displacer		Vertical Displacer	
	Std. ¹	Special ³	Std. ²	Special ³		Std. ¹	Special ³	Std. ²	Special ³
Snap	0.28	0.10	0.21	0.10	Snap	0.28	0.030	0.21	0.050
Throttle	0.56	0.20	0.42	0.20	Throttle	0.56	0.060	0.42	0.100

1. Based upon 1.88" Dia. X 12" Lg. displacer with 12.50" Lg. displacer Arm.
2. Based upon 1.88" Dia. X 12" Lg. displacer with 15.00" Lg. displacer Arm.
3. Special displacer and displacer arm configurations required - consult Factory or your local Mallard Representative.

Model 3200 / 3201

Installation, Operation and Maintenance Instructions

1.3 Model 3200 Parts List



LEFT - HAND MOUNTING SHOWN

ITEM	DESCRIPTION	MALLARD PART NO.	QTY	NAT'L
1	Case Assy (Electric)	80010	1	ALUM
	Case Assy w/o Manifold (Pneumatic)	80243	1	ALUM
	Case Assy w/Manifold (Pneumatic)	80012	1	ALUM
2	Door	80188	1	Buna-N
3	Manifold / Case Gasket	80189	1	Viton
4	Gauge (Output & Supply), 0-30 psi	80016	2	Bronze
	Gauge (Output & Supply), 0-80 psi	80248	2	Bronze
	Gauge (Output & Supply), 0-100 psi	80250	2	Bronze
5	Clamp Kit	80050	1	ALUM
	Clamp	80032	1	SST
	Hex Cap Screw, 250-20 X 2.00"	80028	4	SST
6	Flapper Bar Kit	80052	1	303 SST
	Flapper Bar	80014	1	303 SST
	QR Flapper Bar (Electric)	80015	1	303 SST
	Lock Nut, 10-32	80028	1	SST
	Retaining Ring	80030	1	SST
7	Hex Cap Screw, 25 - 20 x .30	80058	2	SST
8	Fulcrum Kit	80034	1	Nylon
	Thumb Bar, 10-32	80018	1	SST
9	Torque Bar Kit, Standard	80058	1	ALUM
	Torque Bar	80070	1	SST
	Lock Nut, 10-32	80028	1	Vinyl
	Sensitivity Scale	80074	1	Vinyl
10	Level Adjustment Bar Kit	80080	1	ALUM
	Level Adjusting Bar	80048	1	SST
	Level Adjusting Screw, 250-28	80082	1	SST
	Hex Jam Nut, 250-28	80050	1	SST
	Hex Cap Screw, 250-28 X .760"	80048	2	SST
11	Hex Cap Screw, 375-24 X .60"	80098	1	SST
12	Hex Jam Nut, 375-24	80098	1	SST
13	Stud, 375-24 X 2.12"	80094	1	SST
14	Lower Spring Retainer	80068	1	ALUM
15	Spring, Medium Duty (none)	80040	1	316 SST
	Spring, Light Duty (green)	80036	1	316 SST
	Spring, Heavy Duty (yellow)	80042	1	316 SST
	Spring, X-Heavy Duty (red)	80044	1	316 SST

ITEM	DESCRIPTION	MALLARD PART NO.	QTY	NAT'L
16	Upper Spring Retainer	80054	1	ALUM
17	Manifold / Pilot Gasket	80034	1	Buna-N
		80032	1	Viton
18	Snap Pilot	80188	1	Viton
	Throttle Pilot	80188	1	Viton
20	Body	See Table	1	101B CB
21	Spacer	80082	1	303 SST
22	Flat Washer	80092	1	SST
23	Shaft	80084	1	303 SST
		80086	1	316 SST
* 24	Body / Case O-Ring	80086	1	Buna-N
25	Block Bearing	80088	1	303 SST
		80088	1	316 SST
* 26	Block Bearing D-Ring	80078	2	Buna-N
		80078	2	Viton
* 27	Back-Up Ring	80078	2	TFE
* 28	Shaft O-Ring	80082	2	Buna-N
		80084	2	Viton
28	Signal	80100	1	SST
30	Switch, Ex-Proof, DPDT	80238	1	EX-Q
	Switch, Ex-Proof, SPDT	80240	1	EX-Q
31	Hex Cap Screw, 10-32 X 0.38"	80244	2	SST
32	500" x 2.50" Pipe Nipple	80244	1	303 SST
33	O-Ring	80078	1	Buna-N
34	Pipe Elbow, 50" NPT	80248	1	N L/PLTD
35	Door Gasket	80086	1	Nedraene
* 36	Displacer Arm, HORIZONTAL (12.5")	80178	1	304 SST
	Displacer Arm, VERTICAL (12.0")	80180	1	304 SST
	Displacer, 1.88" x 12.00"	80184	1	PVC
	Displacer, 2.00" x 14.00"	80188	1	PVC
	Displacer, 1.88" x 12.00"	80170	1	Aerlyte
	Displacer, 2.00" x 14.00"	80172	1	SST
	Displacer, 1.88" x 12.00"	80172	1	SST
38	Displacer Extension Kit	80086	1	SST
39	Manifold	80264	1	Alum
40	Hex Bar, 250-28 x 1.625"	80080	6	SST
41	Block Bearing (capped)	80061	1	303 SST
		80063	1	316 SST
42	Screen	10014	1	SST

* INCLUDED IN SOFT-COODS KIT
 † DISPLACER ARMS ARE SIZED FOR SPECIFIC APPLICATIONS. SPECIFY EXACT LENGTH WHEN RE-ORDERING.
 †† SPECIAL DISPLACER SIZES AND CONFIGURATIONS ARE AVAILABLE FROM THE FACTORY UPON REQUEST
 ‡ MEETS NACE MR-01-73 SPECIFICATIONS








TABLE 1

CONN	2.00"	3.10"	4.00"	6.00"
NPT	60108	N/A	N/A	N/A
1500# RF	60108	60122	60138	60150
3000# RF	60110	60124	60138	60152
6000# RF	60112	60126	60140	60154
8000# RJ	60114	60128	60142	60156
1000# RF	60113	60127	60141	60155
8000# RJ	60116	60130	60144	60158
15000# RF	60117	60131	60145	60159
15000# RJ	60118	60132	60148	60160
22500# RJ	60120	60134	60148	60162

REPAIR KITS

DESCRIPTION	PART NO.
SNAP PILOT REPAIR KIT	60082
THRUSTLE PILOT REPAIR KIT	60084
SOFT-60009 REPAIR KIT, BUINA-N	60085
SOFT-60009 REPAIR KIT, VITON	60088
MARINE INSULATOR KIT	60070




MARINE OPTION

ITEM	DESCRIPTION	PART NO.	QTY	MAT'L
7	Hex Cap Screw	60056	2	SST
8	Torque Bar Kit, Marine	60058	1	
	Torque Bar	60072	1	303 SST
	Lock Nut, 10-32	60020	1	SST
	Sensitivity Seals	60074	1	Vinyl
10	Level Adjustment Bar Kit, Marine	60028	1	
	Level Adjusting Bar	60049	1	SST
	Level Adjusting Screw, #20-28	60052	1	SST
	Hex Jam Nut, #20-28	60060	2	SST
	Hex Cap Screw, 250-28 X 760"	60046	2	SST
14	Lower Spring Retainer, Marine Service	60066	1	303 SST
18	Insulator Gasket	60236	1	Phenolic

Model 3200 / 3201

Installation, Operation and Maintenance Instructions

1.4 Model 3201 Parts List



ITEM	DESCRIPTION	MALLARD PART NO.	QTY	MAT'L
1	Case Ass'y 3201	60001	1	ALLN
2	Door	60024	1	ALLN
3	Gauge (Supply), 0-30 psi Gauge (Supply), 0-60 psi	60022 60340	1	Bronze
4	Gauge (Output), 0-30 psi Gauge (Output), 0-60 psi	60020 60341	1	Bronze
5	Flapper Bar Kit Flapper Bar Lock Nut, 10-32 Retaining Ring	80082 80014 80026 80030	1	303 SST
6	Hex Cap Screw	80008	2	SST
7	Fulcrum Kit Fulcrum Thumb Screw, 10-32	80054 80036 80018	1	Nylon
8	Torque Bar Kit, Standard Torque Bar Lock Nut, 10-32 Sensitivity Scale	80058 80070 80026 80074	1	ALLN
9	Level Adjustment Bar Kit Level Adjusting Bar Level Adjusting Screw, 260-28 Hex Jam Nut, 250-28 Hex Cap Screw, 250-28 X .750"	80080 80048 80082 80060 80048	1	ALLN
10	Screen	10014	1	SST
11	Stud, .375-24 X 2.12"	80004	1	SST
12	Lower Spring Retainer	80088	1	ALLN
13	Spring, Medium Duty (none) Spring, Light Duty (green) Spring, Heavy Duty (yellow) Spring, X-Heavy Duty (red)	80040 80038 80042 80044	1	316 SST

ITEM	DESCRIPTION	MALLARD PART NO.	QTY	MAT'L
14	Upper Spring Retainer	60054	1	ALLN
15	Pin	See Table	1	ALLN
16	Body	See Table	1	1018 CS
17	Spacer	80082	1	303 SST
18	Flat Washer	80082	1	SST
19	Shaft	60064 60065	1	303 SST ø.316 SST
20	Block Bearing	80058 60069	1	303 SST ø.316 SST
* 21	Block Bearing O-Ring	80078	2	Buna-N ø Viton
* 22	Back-Up Ring	80080	2	TFE
* 23	Shaft O-Ring	80082 80084	2	Buna-N ø Viton
24	Spindle	80100	1	SST
25	Hex Cap Screw, 10-32 X 0.38	80242	2	SST
26	Door Gasket	60056	1	Neprene
† 27	Displacer Arm, HORIZONTAL (12.6") Displacer Arm, VERTICAL (18.0")	80178 80180	1	304 SST 304 SST
†† 28	Displacer, 1.88" x 12.00" Displacer, 2.00" x 14.00" Displacer, 1.88" x 12.00" Displacer, 2.00" x 14.00" Displacer, 1.68" x 12.00"	80184 80186 80188 80170 80172	1	PVC PVC Acrylic SST
28	Displacer Extension Kit	80088	1	SST
30	Hex Nut, .375-24	80080	1	SST
31	Block Bearing (capped)	60061 60063	1	303 SST ø.316 SST
32	BRASS FITTING	60194	2	BRASS

* INCLUDED IN SOFT-GOODS KITS

† DISPLACER ARMS ARE SIZED FOR SPECIFIC APPLICATIONS. SPECIFY EXACT LENGTH WHEN RE-ORDERING.

†† SPECIAL DISPLACER SIZES AND CONFIGURATIONS ARE AVAILABLE FROM THE FACTORY UPON REQUEST.

◇ MEETS NACE MR-01-75 SPECIFICATIONS





TABLE 1


CONN.	2 00*	3 00*	4 00*	6 00*
NPT	60106	N/A	N/A	N/A
150# RF	80108	60122	6D136	6D150
300# RF	80110	60124	6D138	6D152
600# RF	60112	60126	6D140	6D154
800# RJ	80114	60128	6D142	6D156
900# RF	80113	60127	6D141	6D155
900# RJ	60116	60130	6D144	6D158
1500# RF	80117	60131	6D145	6D159
1500# RJ	80118	60132	6D146	6D160
2500# RJ	60120	60134	6D148	6D162

REPAIR KITS

DESCRIPTION	PART NO.
SNAP PILOT REPAIR KIT	80082
THROTTLE PILOT REPAIR KIT	80084
SOFT-GOODS REPAIR KIT, BUNA-N	80085
SOFT-GOODS REPAIR KIT, VITON	80088

PILOTS


DESCRIPTION	PART NO.
SNAP	60186
THROTTLE	60188
SNAP WITH GAUGES/FITTINGS	85016
THROTTLE WITH GAUGES/FITTINGS	85018



Model 3200 / 3201

Installation, Operation and Maintenance Instructions

1.5 Dimensions



1. 16.15" dimension based upon standard vertical service configuration of 15" arm with a 12" lg. displacer. Other arm lengths and displacer sizes are available upon request. 24.50" dimension based upon standard horizontal service configuration of 12.50" arm with a 12" lg. displacer. Other arm lengths and displacer sizes are available upon request.

Vessel Connection	Dimension "F"				
	Body Size				
	2.00	3.00	4.00	6.00	8.00
Butt-Weld Sch. 40	6.00	-	-	-	-
Sch. 80	6.00	-	-	-	-
Sch. 160	6.00	-	-	-	-
Sch. XXH	6.00	-	-	-	-
Slip-on	6.00	-	-	-	-
Screwed Male NPT	6.00	-	-	-	-
Grooved	6.00	6.88	6.94	6.04	*
150# RF	6.50	6.56	6.56	6.50	*
150# RTJ	6.69	6.88	6.88	6.69	*
300# RF	6.81	6.75	6.88	6.94	*
300# RTJ	7.06	7.00	7.25	7.19	*
600# RF	7.19	7.12	7.50	7.62	*
600# RTJ	7.25	7.31	7.56	7.69	*
900# RF	8.00	9.63	10.13	*	*
900# RTJ	8.06	9.69	10.19	*	*
1500# RF	8.00	10.25	10.63	*	*
1500# RTJ	8.06	10.31	10.69	*	*
2500# RF	8.50	11.06	11.75	*	*
2500# RTJ	8.56	11.13	11.81	*	*

* Consult Factory.

2.0 INSTALLATION

2.1 Assembly

When you receive your new Mallard model 3200 Level Controller, you should find the following pieces in the shipping container:

- Controller
- Displacer
- Displacer Arm

Other miscellaneous pieces may be included as well, depending on the specifications for your application.

2.2 Start-up

- a. Rock the torque bar back and forth by hand to verify that the displacer arm is not resting against the vessel nozzle. The displacer arm should be centered in the nozzle. Adjust the balance spring compression with the adjusting knob to position the displacer arm.

To raise the displacer arm, turn the adjusting knob **CLOCKWISE** (increasing spring compression). To lower the displacer arm, turn the adjusting knob **COUNTERCLOCKWISE** (decreasing spring compression).

- b. Adjust controller proportional band (sensitivity) by sliding the fulcrum along the flapper bar. To decrease the proportional band (increase controller sensitivity), loosen the thumb screw and slide the fulcrum away from the pivot point (toward the pilot). Tighten the thumb screw when finished.

To increase the proportional band (decrease controller sensitivity), loosen the thumb screw and slide the fulcrum toward the pivot point (away from the pilot). Tighten the thumb screw when finished.

Model 3200 / 3201

Installation, Operation and Maintenance Instructions

3.0 OPERATION

3.1 Theory of Operation

The operation of the model 3200 Liquid Level Controller is based upon the "Force Balance Principle", illustrated in Figure 1. The weight of a displacer-type level sensing element produces a force which is applied to one side of the Torque Bar through a series of shafts and levers. This force is balanced by the opposing force of a compressed spring on the other side of the Torque Bar. As the level rises, the increased immersion of the displacer in the liquid causes the relative weight of the displacer to decrease, due to the buoyancy force being produced. This, in turn, results in a decrease in force applied to the Torque Bar. The Torque Bar then rotates until the forces are again balanced. Torque Bar rotation is detected by the pilot through a fulcrum mounted on a lever (Flapper Bar) to affect the desired controller output. The output signal can be a pneumatic on/off signal by using the snap pilot, a pneumatic modulating signal by using the throttle pilot, or it can be an electrical SPDT or DPDT output signal by using an electric limit switch.



Figure 1

3.2 Level Adjustment

As mentioned above, the balance spring is compressed to a point where the force applied from the spring to the torque bar equals the opposing force caused by the weight of the displacer. The liquid level control point is changed by adjusting the balance spring compression with the adjusting knob, as shown in Figure 2.

To INCREASE the liquid level control point, DECREASE BALANCE SPRING COMPRESSION. An increase in liquid level causes an decrease in the relative weight of the displacer, thereby requiring less opposing force to achieve balance.

To DECREASE the liquid level control point, INCREASE BALANCE SPRING COMPRESSION. A decrease in liquid level causes an increase in the relative weight of the displacer, thereby requiring more opposing force to achieve balance.




Figure 2. Level Adjustment

3.2.1 Liquid Interface

Initial controller setup for interface level applications is as follows:

1. Position fulcrum approximately $\frac{1}{4}$ " from the torque bar snap ring, and slowly reduce spring compression to allow the upper fluid to rise and submerge the displacer.
2. Once submerged in the upper fluid, slowly increase spring compression until an output signal increase is obtained, then slowly remove compression again until the output signal returns to zero. At this point, the controller is ready to control the lower fluid level.

3.3 Proportional Band

Proportional band is the ratio of used displacer length to the total length of the displacer. "Used displacer length" is defined as the change in input (level) that affects a corresponding 100% change in controller output (control valve position). For example, if a change in level of four inches causes the controller output to change from 0% to 100%, and the total displacer length is 12", then the proportional band is 33%. By changing the proportional band to 50%, the change in level to affect the same 100% change in output will then be six inches. Summarily, increasing proportional band (from 33% to 50% in example) is synonymous with decreasing controller sensitivity (4" to 6" change in example), and vice versa.

3.3.1 Proportional Band Adjustment

Figure 3 illustrates the controller's proportional band adjustment.

To decrease the proportional band (increase controller sensitivity), loosen the thumb screw and slide the fulcrum away from the pivot point (toward the pilot). Tighten the thumb screw when finished.

To increase the proportional band (decrease controller sensitivity), loosen the thumb screw and slide the fulcrum toward the pivot point (away from the pilot). Tighten the thumb screw when finished.

Model 3200 / 3201

Installation, Operation and Maintenance Instructions




Figure 3. Proportional Band Adjustment

3.4 Controller Mounting

The model 3200 Liquid Level Controller can be set up as Right Hand Mount or Left Hand Mount. The orientation of the level controller mounted to the vessel, while facing the front of the controller, determines the mounting style, illustrated in Figure 5. If the controller is to be mounted on the right side of the vessel, then it is considered "Right Hand". If the controller is to be mounted on the left side of the vessel, then it is considered "Left Hand". The mounting orientation can be easily reversed in the field.

3.4.1 Mounting Orientation Conversion

Figure 4 identifies the various controller parts referenced in this section.

Disassembly:

1. Remove balance spring compression with the adjusting knob.
2. Remove the balance spring and upper spring retainer from the controller.
3. Remove the spring stud bolt and lower spring retainer from the controller.
4. Remove the lock nut (7/16" wrench) which holds the torque bar in place, and remove the torque bar from the controller.
5. Remove the lock nut (7/16" wrench) which holds the flapper bar in place, and remove the flapper bar from the controller.
6. Loosen the two hex head cap screws (1/2" box-end wrench) that secure the level adjusting bar to the controller shaft. When the screws are sufficiently loosened so that the level adjusting bar is not compressed onto the shaft, slide the level adjusting bar off of the shaft, and remove the spacer from the shaft, as well.
7. Remove the two hex head cap screws that attach the controller case to the controller body.
8. Remove the case from the controller body.

Conversion and Re-Assembly:

1. Position controller case on controller body to achieve the desired mounting configuration, and install the two hex head cap screws into the case mounting holes. Tighten to 6 ft-lbs of torque.
2. Slide spacer on the shaft, then slide the level adjusting bar in place on the shaft. Make sure that the level adjusting screw is positioned such that there is an equal number of threads exposed above and below the level adjusting bar.
3. Snug up the two hex head cap screws on the level adjusting bar. Do not fully tighten yet.
4. Slide the torque bar onto the shaft temporarily to position the level adjusting bar. Position the level adjusting bar so that the torque bar is parallel with the displacer arm when the round tip of the level adjusting screw is touching the torque bar. Remove the torque bar while holding the level adjusting bar in position, then tighten the cap screws to firmly secure the level adjusting bar in place. Tighten the screw nearest the slotted end of the level adjusting bar first.

5. Slide the torque bar back onto the shaft. Make sure that the countersunk hole for the balance spring upper retainer is facing down. Install the lock nut on the end of the shaft to hold the torque bar in place.
6. Slide the flapper bar onto the pivot pin (see Section 3.5, Controller Action, to determine the proper installation of the flapper bar for your application) and install the retaining lock nut. The flapper bar must be free to pivot. Therefore, do not apply an excessive amount of torque to the lock nut.
7. Install balance spring stud bolt and lower spring retainer. For left-hand mounting, the stud bolt is installed on the right side. For right-hand mounting, the stud bolt is installed on the left side.
8. Install the balance spring and the upper spring retainer. Engage the upper spring retainer with the countersunk hole in the torque bar.
9. Apply compression to the balance spring with the spring adjusting knob.




Figure 4. Level Controller Internals

3.5 Controller Action

Controller action is determined by the installation of the flapper bar, as shown in Figure 5. Control is considered “Direct-Acting” when the controller output changes in the same direction as the liquid level. For example, the controller output signal will increase as the liquid level increases, and vice versa. Control is considered “Reverse-Acting” when the controller output changes in the opposite direction as the liquid level. For a direct-acting controller, the flapper bar pivot point is on the same side as the balance spring. For a reverse-acting controller, the flapper bar pivot point is on the opposite side as the balance spring.

3.5.1 Controller Action Conversion

To convert the controller from Direct-Acting to Reverse-Acting, or vice versa, the following procedure should be followed:

1. Relieve balance spring compression with the adjusting knob.
2. Remove pivot pin lock nut, and slide the flapper bar off of the pivot pin.

Model 3200 / 3201

Installation, Operation and Maintenance Instructions

3. Remove the thumb screw from the fulcrum, and replace the thumb screw into the screw hole on the opposite side of the fulcrum.
4. Connect the flapper bar to the pivot pin on the opposite side of the controller housing.
5. Install the pivot pin lock nut to hold the flapper bar in place.
6. Adjust the balance spring compression with the adjusting knob.





Figure 5. Controller Mounting and Action Configurations

3.6 Snap Pilot Operation

The snap pilot is made up of two valves: one to admit system supply pressure, and one to exhaust system pressure. Ball "X" controls the flow of supply gas into the pilot and is held closed on the pilot seat by force exerted by the supply pressure acting upon the seating area of the ball.

When force transmitted from the flapper bar to the thrust pin "Y" becomes sufficient to overcome the force holding ball "X" seated, ball "X" snaps off the pilot seat allowing supply gas to flow past ball "X" and through the output port of the pilot. The spherical seating end of the thrust pin "Y" seats and closes the exhaust port simultaneously when ball "X" snaps open. The seating area of the thrust pin is smaller than the seating area of ball "X"; therefore, the thrust pin must remain seated against the supply pressure until force on the thrust pin from the flapper bar diminishes.




A simultaneous action occurs as force from the flapper bar on the thrust pin "Y" is removed. When this happens, the supply pressure will unseat the thrust pin and open the exhaust port in the pilot and ball "X" will re-seat and close off the supply port. The difference in seating areas give this pilot its "snap" action.

3.7 Throttle Pilot Operation

The throttle pilot, like the snap pilot, is also made up of two internal valves. In addition, the throttle pilot utilizes a resilient diaphragm "Z" in conjunction with the valves to create a Force Balance Pilot.

The pilot output supply pressure acts upon the diaphragm "Z" so that the diaphragm pushes back with the same force being applied to the thrust pin by the flapper bar, thus the term *Force Balance*.

The throttle pilot functions in a similar manner as the snap pilot except that the output pressure is proportional to the amount of force applied to the lower seat by the flapper bar. An increase in force on the peanut produces a proportionate increase in pilot output pressure.



As forces change on the peanut, the pilot seeks a new balance point by exhausting the supply output at valve "Y" or unseating valve "X" to increase output pressure. Supply gas does not flow while the pilot is in balance.

Model 3200 / 3201

Installation, Operation and Maintenance Instructions

4.0 MAINTENANCE

4.1 Preventive Maintenance

The model 3200 Level Controller is specifically designed to provide maintenance-free service in the harsh environments found in oil and gas production and transmission facilities, and should last for many years without any special maintenance requirements. Should leakage occur, replace the O-ring seals. Refer to the parts list in Section 1.3 for ordering information on replacement parts and repair kits.

4.2 Troubleshooting

Symptom	Probable Cause	Corrective Action
Direct-Acting ¹ controller is producing output signal when liquid level is below ⁽¹⁾ the displacer.	<p>a. The balance spring is overly compressed.</p> <p>b. The displacer arm is set too high, or the displacer is encountering an obstruction inside the vessel.</p> <p>c. Foreign matter has entered the pilot valving and prevented proper seating of the pilot components.</p>	<p>a. Remove spring compression with the adjusting knob until the output signal goes to zero. Recheck when the liquid level rises.</p> <p>b. Check for freedom of movement by rocking the torque bar by hand. If the torque bar will only move in one direction, turn the level adjusting screw to bring the displacer arm down to allow freedom of movement.</p> <p>c. Disconnect supply and output tubing. Remove the four screws from the pilot clamp so that the pilot can be extracted. Disassemble the pilot and clean thoroughly. Reassemble the controller and follow the recommended start-up procedures.</p>

1. For Reverse-Acting controllers, the same corrective action will apply, but the symptoms will be reversed.

(continued)

4.2 Troubleshooting (continued)

Symptom	Probable Cause	Corrective Action
Direct-Acting ¹ controller is producing no output signal when liquid level is above ⁽¹⁾ the displacer.	<p>a. The balance spring is under compressed.</p> <p>b. The displacer arm is set too low, or the displacer is encountering an obstruction inside the vessel.</p>	<p>a. Increase spring compression with the adjusting knob until an output signal is indicated on the controller output gauge. Output pressure should then go off when fluid level drops. Make further adjustments to spring compression as necessary to affect the desired results.</p> <p>b. Check for freedom of movement by rocking the torque bar by hand. If the torque bar will only move in one direction, turn the level adjusting screw to bring the displacer arm up to allow freedom of movement.</p>
Control is sluggish and non-repeatable; may fail to either produce output signal or remove output signal.	The displacer or displacer arm is encountering an obstruction (foreign debris, paraffin buildup, etc.) that is inhibiting free movement.	Remove the controller from service and thoroughly clean out the controller body with solvent.
Unstable control of liquid/liquid interface: may lose liquid or may overflow.	Check to ensure that displacer arm is free and that the displacer is not hitting the inside of the vessel. If all is clear, then the displacer is improperly sized.	Obtain exact specific gravities or API gravities of both upper and lower liquids, and contact Mallard for displacer sizing assistance.

1. For Reverse-Acting controllers, the same corrective action will apply, but the symptoms will be reversed.